

# WoodSide Plank INSTALLATION GUIDE

## Required Installation Procedures:

Note: Installation must be in accordance with the instructions provided with the floors.

- \* The sub floor must have no prior history of moisture and be visually dry at the time of installation.
- \* Only American Vintage approved nailers, pneumatic staplers, staplers, glues and mastics may be used for installation.
- \* The products should be thoroughly inspected prior to installation and any visually evident manufacturing defects should be identified prior to installation for replacement. Replacement for these types of issues is only available prior to installation.
- \* If American Vintage approved radiant heat is used under the products, the temperature must be set as to not exceed 90 degrees.